

PLASTIC CART ASSEMBLY INSTRUCTIONS

UCPL1, WE, WT • 2-Shelf Models

Table of Contents

Cart Assembly

Page 2 2-Shelf Plastic Cart Assembly Instructions

Optional Accessories

Page 3	Cabinet Installation Instructions
Page 4	Locking Drawer Installation Instructions
Page 5	Pullout Keyboard Tray Installation Instructions
Page 6	Power Strip & Cord Wrap Installation Instructions

NOTE: This guide includes instructions that may not be applicable to your specific model. Each cart will ship with assembly instructions for the cart and included accessories only. Instructions for accessories will be packaged with each accessory's respective components.

LUZOR | 2-Shelf Plastic Utility Cart Assembly Instructions
Applicable Models: 2-Shelf TC, EC, SEC, STC, BC, HE, HC, LE, LP, and WT-series

www.luxorworkspaces.com | 800-323-4656

PARTS KEY:



Tub Shelves* (SEC, EC, STC, and TC models)



Flat Shelves* (EC, HE, HC, LE, LP, and WT models) 4" Standard Casters

C x 2



Locking Casters

D x 2



Non-Locking Casters

E x 4



Square Legs (WT, SEC, and EC models)

OR

E x 4



Round Legs (LE, LP, STC, TC, and BC models)

REQUIRED TOOLS:



Rubber Mallet (Not included)


IMPORTANT:


If your cart includes options such as a power strip, pullout shelf, locking drawer, or locking cabinet, installation instructions for those components will be included in their packaging.


*NOTE:


Some EC, STC, and TC models come with a mix of flat and tub shelves.

ASSEMBLY INSTRUCTIONS:










Page 2



Tuffy Cart Cabinet Pack Instructions

Please consult your Tuffy cart base unit instructions before starting





Tools Required

- Rubber Mallet




IMPORTANT: Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.
























WT-D Pullout Drawer Instructions

Parts List G X


Tools Required

- Phillips Screwdriver





With a Phillips Screwdriver, attach the drawer assembly to the top shelf with the 4 screws.



LUXOR www.luxorworkspaces.com | 800-323-4656

Pullout Keyboard Shelf Instructions

for Plastic Carts


FR x1


Parts List

H x1 FL x1









Take the top shelf of your plastic cart and lay it flat. Collect parts: **FL**, **FR** & **A**. Align **FR** & **FL** to the outer holes at the top of the shelf. Take screw **A** and fasten with a screwdriver, do not tighten fully until keyboard is attached.


Collect parts: **H**. Align the pullout shelf **H** runner so that the runner snaps into place into the **FL** & **FR** brackets. Pull the shelf out to make sure it is fully seated. Tighten screws **A**. Pullout keyboard shelf assembly is now complete.



www.luxorworkspaces.com | 800-323-4656

Electric Assembly Instructions

Number of outlets may vary.



Tools Required

- Screwdriver





