

SINGLE BATTERY CHARGER KBEP-BASE1

INSTRUCTIONS

Tools Required: None

In the Box:








Single Battery Charger


Ships / Sold Separately:




Rechargeable Battery




Clamp-On Desktop Charging Unit




Battery Charging Options



Plug male end of power cord into Single Battery Charger.



Plug power cord into available AC wall outlet.




Connect Rechargeable Battery to Single Battery Charger.

When fully connected, Rechargeable Battery indicator lights will blink to show charging status.

- 1st dot blinking
 - = 0 to 24% charged
- 2nd dot blinking, 1st dot solid = 25 to 49% charge
- 3rd dot blinking, 1st & 2nd dot solid = 50 to 74% charged
- 4th dot blinking, 1st, 2nd, & 3rd dot solid = 75 to 99% charged

NOTE: Batteries will ship only partially charged and must be fully charged before first use.



Allow two (2) hours for Battery to fully charge.

When all four indicator lights illuminate solid, the Battery is fully charged.

TROUBLESHOOTING

Indicator lights not illuminating*

- 1. Ensure Single Battery Charger is fully plugged in and connected to Battery.
- 2. If step 1 does not work, contact customer service.

*Indicates Rechargeable Battery is not charging when connected to Single Battery Charger.